



HoopMaster Settings

Below are the settings that I have set up for the **HoopMaster** hooping device that match the **Left Chest-Right Chest Design Placement Chart** and the **Placement Grids**. These measurements are ones that I have used for many years and have worked out very well.

I typed out the Sizes as is pictured below, cut it out and taped it to my **HoopMaster** in the lower left corner using the clear packing tape. Do not tape it over the holes, it will interfere if you want to move your template to the left side of the **HoopMaster**.

As you can see, there are settings for Men and Ladies. **There are also settings for using the 12 cm hoop and the 15 cm hoop.** The center is in a little different spot on each hoop.

Mens	12 CM	15 CM	Ladies	12 CM	15 CM
XS	19	14	XS	9	5
S	19	14	S	9	5
M	22	18	M	13	9
L	26	22	L	17	13
XL	31	27	XL	22	18
2XL	31	31	2XL	22	18
3XL	31	31	3XL	26	22